



Sand Screen Discs

Sand Screen Discs are commonly used for removal or repair of coatings on wood floor surfaces. Screen discs are also used in the final stages of floor sanding to smoothen raised grain. Available in standard round styles for conventional floor machines and rectangular discs designed for oscillating machines.

Sand Screen Discs

Use

Sand Screen Discs are commonly used for removal or repair of coatings on wood floor surfaces. An ideal application would be refinishing gym floors. They are also used for repair of painted floor surfaces. Use both sides of the Sand Screen Disc. May be used either wet or dry. Use a screen driver pad to prevent screen slippage and to maximize performance. Use with conventional or oscillating floor machines.

Construction

Sand Screen Discs are constructed with water proof resins and silicon carbide abrasives on both sides of the discs.

Product Care

Screens may be rinsed and reused to prolong sanding life. Rinsing the screens removes debris and build up in the screen, allowing for a clean cutting surface.

Note: Due to the intrinsic properties of the material and variable conditions of use, There may be slight variations in the specifications and results.